
INSTRUCTIONS

IMPORTANT SAFEGUARDS

When using electrical equipment, basic safety precautions should always be followed including the following:

1. **READ AND FOLLOW ALL SAFETY INSTRUCTIONS**
2. Disconnect power before performing work on electrical equipment
3. Do not let power cords touch hot surfaces and do not mount near gas or electric heaters.
4. Equipment should be mounted in locations and at heights where unauthorized personnel will not readily subject it to tampering.
5. The use of accessory equipment not recommended by BeLuce Canada Inc., may cause an unsafe condition, and will void the unit's warranty.
6. Do not use this equipment for other than its intended purpose.
7. Servicing of this equipment should be performed by qualified service personnel.
8. **SAVE THESE INSTRUCTIONS!**

INSTALLATION

1. Carefully unpack the unit from the box.
2. The fixture is supplied complete with canopy for wall or ceiling mount.
3. Extend unswitched supply of DC voltage to certified wet location junction box (supplied by others) from terminals on charger board of battery unit (if applicable) or other supply of DC voltage of 12V to 24V.
4. Make positive and negative connections inside junction box. Note: polarity is important.
5. Position gasket between canopy and junction box.
6. Secure the remote head using two screw hole slots on canopy. The two screw hole slots are designed to mate with standard style junction box.
7. Restore DC power to ensure operation of remote heads. Aim lights as required. Use an open end wrench to tighten and lock in place.

MAINTENANCE

1. Clean lenses on a regular basis.

NOTE: The servicing of any parts should be performed by qualified service personnel only. The use of replacement parts not furnished by BeLuce Canada Inc., may cause equipment failure and will void the warranty.

Figure 1

