

---

## INSTRUCTIONS

### IMPORTANT SAFEGUARDS

When using electrical equipment, basic safety precautions should always be followed including the following:

1. **READ AND FOLLOW ALL SAFETY INSTRUCTIONS**
2. Disconnect power before performing work on electrical equipment.
3. Do not let power cords touch hot surfaces and do not mount near gas or electric heaters.
4. Use caution when servicing batteries. Battery acid can cause burns to skin and eyes. If acid is spilled on skin or eyes, flush with fresh water and contact a physician immediately.
5. Equipment should be mounted in locations and at heights where unauthorized personnel will not readily subject it to tampering.
6. The use of accessory equipment not recommended by BeLuce Canada Inc. as it may cause an unsafe condition, and will void the unit's warranty.
7. Do not use this equipment for other than its intended purpose.
8. Servicing of this equipment should be performed by qualified service personnel.
9. **SAVE THESE INSTRUCTIONS!**

---

## INSTALLATION

(see Figure 1) : WG Unit

1. Carefully unpack the wireguard from its packaging.
2. The wireguard provided is made from 10 & 12 gauge cold rolled steel and finished with a powder coat finish. Its intended purpose is to provide emergency equipment protection from physical damage. A variety of sizes are available.
3. The wireguard should not touch the emergency equipment. Leave at least a ½" clearance around the product from the wireguard.
4. Ensure the product is mounted high enough to avoid tampering.
5. Simply secure the wireguard to the mounting surface with four screw type fasteners (supplied by others). The screw should be inserted through the metal loops provided in the four corners of the wireguard.
6. Your product is now protected from accidental damage or abuse.

**Figure 1**

